



*superior video technology*

CORPORATE

SALES

PRODUCTS

SUPPORT

Downloads

FAQs

Manuals

Warranty Info

Contact Support

## TVIEW MICRO

### Problem

### Possible Causes/Solutions

No computer image on the TV, screen is snowy, or has TV program on it

TV or VCR is not set for video input mode. Set the TV or VCR to Video Input. To set the TV or VCR to video input mode it is usually a button on the remote control or front panel for the TV or VCR, or an on-screen menu option. It may be called INPUT, VIDEO, AUX, LINE, VIDEO CHANNEL etc. Refer to the TV or VCR's owners manual for further assistance.

Video cable from TView Micro may not be connected to the correct input on the TV or VCR.

TV screen is black, still no computer image

Check to make sure that the TView Micro has power. At least one of the LED's on the top of the unit should be lit. If not make sure you have connected either the USB or Keyboard power cable from the Computers USB or Keyboard port and the other end is connected to the TView Micro KB/DC jack.

Check to make sure that your computer is powered ON and connected properly to the TView Micro unit.

Verify that the computer is sending a good signal from the Monitor out port. The TView Micro VGA light should be lit if it is receiving a valid signal from the computer.

	<p>If you are using a laptop, verify that you have activated the external VGA port, usually by pressing a combination of the "Fn" key on your keyboard along with one of the Function keys, usually labeled "LCD/CRT", or with a picture of a computer monitor. Refer to your laptop's documentation for the exact key combination.</p>
<p>TV screen has colored, distorted lines on the screen, still no computer image</p>	<p>cSome Computers may not provide enough current to drive the TView Mciro electronics via the USB port. Try using the Keyboard power cord instead.</p> <p>Use of an RF Modulator may cause image quality problems. If at all possible, avoid those devices that convert the TView Gold signal into an antenna signal.</p>
<p>TV image overshoots or fails to fill the screen</p>	<p>Use the PIC/SIZE controls to adjust size and positioning.</p>
<p>TView Micro</p>	<p>Inspect the TView Micro unit for signs of damage (i.e. broken pins, severed wires, etc.).</p>